



## **User Manual**

**Door Camera** CIOT-D20M



www.commax.com COMMAX Co.,Ltd.



- · Thank you for purchasing COMMAX products.
- Please carefully read this User's Guide (in particular, precautions for safety) before using a product and follow instructions to use a product exactly.
- The company is not responsible for any safety accidents caused by abnormal operation of the product.



1. Introduction	•••••	 •	2
2. Part Names		 	3
3. Wiring and Ir	stallation·····	 	4
4. Package Cor	itents ·····	 	5
5. Specification		 	6



Your unit is designed so it can be flush mounted on the or used. When flush mounted on the wall, the stand permils you to the unit for an gular of unit view. The model number is located on the bottom and record the serial number in the space provided below(available). Refer to these numbers whenever you call upon your COMMAX dealer regarding this product.

Model No. Serial No.

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

This symbol is intended to alert the use to the presence of uninsulated "dangerous Voltage" within the product's enclose that may be of sufficient magnitude to constitute a risk of electric shock to persons.

This symbol is intended to alert the use to the presence of important operating and maintemance(servicing) instructions in the literature accompanying the appliance



#### caution


Rosk of electric shock do not open




CAUTION: To reduce the risk of electrix shick, do not remove cover(or back) no user-serviceable part sinside refer servicing to quaured service personnel



#### 2. Part Names






No.	Information	No.	Information	
1	LED & CDS	6	DC 12V (Option)	
2	Camera Lens	7	Door Release Connection	
3	MIC	8	Reset	
4	Call Button	9	PoE	
5	Speaker	10		

<sup>\*8.</sup> Reset: Press the Reset button for 5 seconds, You can initialize status of Camera.



#### 3. Wiring and Installation




- Fix a bracket on a wall with screws
- 2 Connect UTP and Door release cable on te back side of a door camera
- (3) Put a Door camera unit into a wall bracket.
- 4 Tighten a screw at the bottom side of a door camera.



### 4. Package Contents



DOOR CAMERA



WALL BRACKET









# **5.** Specification

Model Spec	CIOT-D20M	
Wiring	UTP (CAT.5e)	
Voltage	INPUT : PoE DC 36V ~ 54V	
Power Consumption	Standby :5W , Max :12W	
Transmission	Audio: VoIP(SIP Standard), Video: H.264 / H.265 / Onvif	
Wiring & Distance	UTP (CAT.5e) Standard 70m	
	(Standard distance from POE S/W)	
Temperature	-10°C ~ +40°C	
Video	Onvif	
Mount Type	Wall mounted	
Angle	120°	
OS	Linux	
Fixel	2Mega Pixel FHD	
Dimension (mm)	110(W)×145(H)×28(D)	

# COMMAX

COMMAX Co.,Ltd.

513-11, Sangdaewon-dong, Jungwon-gu, Seongnam-si, Gyeonggi-do, Korea Int'l Business Dept.: Tel.; +82-31-7393-540~550 Fax.; +82-31-745-2133 Web site: www.commax.com

PM49D20M0010 Printed In Korea / 2016.04.105